

ICC Profile Print Settings

The settings listed below are to be used when you are using an ICC Profile to print. These ICC Profiles are available for download on our website. The ICC Profile handles the color management when printing. The media types listed control the ink densities and linearization for each media.

TROUBLESHOOTING: If you are having trouble downloading and installing our ICC Profiles or with the settings listed below, please watch our instructional videos at www.breathingcolor.com/page/videos

Please note: Recommended Media Type/Black ink listed in BOLD

EPSON Printers

Stylus Pro 4800 | 4880 | 4900 | 7800 | 7880 | 7900 | 7890 | 9800 | 9880 | 9900 | 9890 | 11880

For these products: →

- Lyve Canvas
- Chromata White Canvas
- 800M Canvas
- Elegance Velvet Fine Art Paper
- Optica One Fine Art Paper
- 600MT Fine Art Paper
- 28MT Fine Art Paper

Use these settings in the Epson Driver:

- Print Preview Window: Under Color Management, set Color Handling to "Photoshop Manages Colors"
- Printer Profile - Use corresponding ICC Profile for media
- Rendering Intent - Perceptual
- Use Black Point Compensation
- Page Setup (Printer Settings if using Adobe CS5)
- Media Settings - Media type:
Watercolor Paper-Radiant White (Matte Black ink), or Premium Glossy Photo Paper (Photo Black ink)
- Print Quality: SuperFine 1440x720dpi
- Paper Configuration: Platen Gap (Wider)
- Mode: (Custom) No Color Adjustment
- Paper Settings - Roll Paper (Banner)
- Roll Paper Option: Auto Cut OFF
- Paper Suction: Standard

- Vibrance Luster Photo Paper*** →
- Vibrance Rag

Use all of the same settings above, EXCEPT:

- Media type: **Premium Luster Photo Paper (Photo Black)**, or Textured Fine Art Paper (Matte Black)
- Paper Configuration: Platen Gap (Standard)

- Vibrance Gloss Photo Paper →

Use all of the same settings above, EXCEPT:

- Media type: **Premium Glossy Photo Paper (Photo Black)**, or Textured Fine Art Paper (Matte Black)
- Paper Configuration: Platen Gap (Standard)

- Vibrance Metallic →

Use all of the same settings above, EXCEPT:

- Media type: **Premium Glossy Photo Paper 250 (Photo Black)**
- Paper Configuration: Platen Gap (Standard)

- Crystalline Gloss Canvas →
- Crystalline Satin Canvas

Use all of the same settings above, EXCEPT:

- Media type: **Canvas (Photo Black)**
- Paper Configuration: Platen Gap (Wider)

Vibrance Luster Photo Paper was designed specifically to be a direct plug and play replacement for "Premium Luster Photo Paper", therefore you can use the existing Premium Luster Photo Paper ICC profile already included in your Epson driver.